

Tabla para Motores Monofásicos: Amperaje del Motor en HP, CA

Caballos de Fuerza	115 V	208 V	230 V
1/6	4.4	2.4	2.2
1/4	5.8	3.2	2.9
1/3	7.2	4.0	3.6
1/2	9.8	5.4	4.9
3/4	13.8	7.6	6.9
1	16.0	8.8	8.0
1 1/2	20.0	11.0	10.0
2	24.0	13.2	12.0
3	34.0	18.7	17.0
5	56.0	30.8	28.0
7.5	80.0	44.0	40.0
10	100.0	55.0	50.0

Tabla para Motores Trifásicos: Amperaje del Motor en HP, CA

Caballos de Fuerza	208 V	230 V	460 V
1/2	2.2	2.0	1.0
1/4	5.8	3.2	2.9
1	4.0	3.6	1.8
1 1/2	5.7	5.2	2.6
2	7.5	6.8	3.4
3	10.7	9.6	4.8
5	16.7	15.2	7.6
7 1/2	24.0	22.0	11.0
10	31.0	28.0	14.0
15	46.0	42.0	21.0
20	59.0	54.0	27.0
25	75.0	68.0	34.0
30	88.0	80.0	40.0
40	114.0	104.0	52.0
50	143.0	130.0	65.0
60	170.0	154.0	77.0
75	211.0	192.0	96.0
100	273.0	248.0	124.0
125	342.0	312.0	156.0
150	396.0	360.0	180.0
200	528.0	480.0	240.0